


























ERODIN 1D1W1S






KÓD	ROZMĚR			BALÍČEK	
	2078	360	16/32	1	1/3
002	2078	360	16/32	1	1/3
003	556	362	22	1	1/3
005	376	482	16	1	1/3
006	488	334	16	1	1/3
007	488	290	5	3	3/3
008	488	284	16	1	1/3
014	488	60	16	1	1/3
015	488	60	16	1	1/3
017	1401	507	3	1	1/3
018	619	507	3	1	1/3
019	2078	360	16/32	1	1/3
020	1364	482	16	1	2/3
021	482	170	16	1	1/3
022	432	100	16	1	1/3
023	300	100	16	1	1/3
024	300	100	16	1	1/3
028	488	70	30	2	1/3
036	450	302	3	1	1/3
PRÍSLUŠENSTVÍ				1	1/3











x2 e1 Ø 7x50mm 	x14 r1 Ø 15x12mm 	x14 r16 	x6 s2 
x32 f1 Ø 8x30mm 	x5 a143 	x5 b119 	x10 s4 
x6 l2 	x1 n260 	x31 p25 Ø 3,5x16mm 	x12 d3 Ø 5x17 mm 
x1 f3 Ø 10x50 mm 	x1 n14 	x1 p17 Ø 6x60 mm 	x4 k1 
x1 L300 	x1 z1 		








POZOR! Nábytek je nutné pevně připevnit ke zdi, abychom se vyhnuli riziku spojenému s jeho převrnutím. Součástí balení nejsou připevňovací šrouby, protože způsoby připevnění je nutné zvolit podle druhu stěny. Vyberte správný pro Váš typ stěny.





1




2




3




4




5




6




7




8




9



10



10



11

