
























NÁVOD NA MONTÁŽ


TV-5010

 1	 2	 3	 4	
 5	 6	 5 KS 7	 4 KS 8	
 9	 10	 11	 12	
 M6*18 4 KS A	 M8*50 2 KS B	 M8*25 2 KS C	 M8*40 18 KS D	 M8*55 1 KS E
 M8 3 KS F	 8*22*2 18 KS G	 M6*20 8 KS H	 I	 M8 M6 M5 J

1




2



3

1



4

6

G


D

8

11

10

H



5

H

4



6

